Tunstall

INSTRUCTIONS





Opening

- 1. Open shutter hatch to reveal the dial and the opening lever
- 2. Dial existing combination, otherwise factory default 0.0.0.0
- 3. Press down on the opening lever

Setting new combination

Open the Sentinel door to reveal the setting mechanism (refer to the above)

- 2. Push the reset lever left and towards you and the reset lever will stay in position.
- 3. Rotate dials to your preferred combination.
- 4. Push the reset lever up and away from you to return to original position. Double-check your combination before closing the storage compartment door
- 5. Close the storage compartment.
- 6. Scramble the combination dials to lock the Sentinel and conceal your combination.
- 7. Close the shutter hatch.



Opening your shackle

- 1. Open your lock (refer to above).
- 2. Slide the Release Lever in direction of the arrow.
- 3. Open lock Shackle.
- 4. Then remove Shackle.
- 5. Affix to suitable anchor.

Closing your shackle

- 1. Holding the Slide Lever in the direction of the arrow.
- 2. Relocate Shackle into lock.
- 3. Then release Slide Lever.



NOTES:

Release Lever

- We suggest that you mount the lock in a discrete location away from direct view, such as porches, garage, out of direct eye line.
- Keep shutter hatch closed to increase weather resistance and to conceal the dials from view.